# Security Modules with Hinged Doors

ASSEMBLY INSTRUCTIONS

CAUTION
INSPECT CONTENTS IMMEDIATELY AND FILE CLAIM WITH DELIVERING CARRIER FOR ANY DAMAGE. **SAVE YOUR BOX AND ALL PACKING MATERIALS.** YOU ARE RESPONSIBLE FOR DAMAGE TO YOUR UNIT IF RETURNED IMPROPERLY PACKED.

security module with hinged doors— shown attached to shelf unit

Parts List

(1) rear panel

(1) left door

(1) right door

(2) end panels

EG10086   Revised 05/25

EAGLE GROUP®
*Profit from the Eagle Advantage®*

• 100 Industrial Boulevard, Clayton, Delaware 19938-8903 U.S.A.
• Phone: 302/653-3000 • 800/441-8440 • Fax: 302/653-2065
• www.eaglegrp.com • www.eaglemhc.com

Security Modules
with Hinged Doors

Step 1 - Determine location of security module by positioning bottom wire shelf (not included) accordingly onto posts.

split sleeves

corner collar

post

split sleeve

post

lower wire shelf

Step 2 - Install end panels by sliding loops over and down the front and rear posts on each end, with the bottom of each panel locking into bottom wire shelf.

right end panel

rear post

left end panel (in place)

front post

bottom wire shelf

Step 3 - Install rear panel by sliding loops over and down the rear posts, with the bottom of the panel locking into bottom wire shelf.

rear panel

rear post

rear panel

(rear view)

lower wire shelf

Security Modules
with Hinged Doors

Step 4 - Install left and right doors by sliding loops over and down the front posts.

left door

right door (in place)

front post

front post

Step 5 - Install top wire shelf (not included) onto top of posts. Rear panel and end panels should lock into top wire shelf.

NOTE: To install top wire shelf, doors must be in the open position.

top wire helf

split sleeves

top wire shelf

split sleeve

post

(End)

Assembly is complete.

Security Modules
with Hinged Doors